SPRING REVERB

TANK CONNECTION GUIDE

3FACO



- Never connect external sound sources to the module's RCAs.
- Always check that the RCA cables leading to the tank are shielded.
- Always use compatible tanks around Input: 190 Ω and Output: 2,5 Ω.

IMPORTANT!

WARNING: DO NOT CONNECT THE SPRING REVERB MODULE TO THE TANK WHILE THE MODULE IS POWERED. DISCONNECT THE POWER FROM YOUR MODULE BEFORE YOU ATTEMPT TO CONNECT THE REVERB TANK!